



MOBILE TREATMENT
for
Emergency Response and
Alternative Ballast Management

ALAN J. ORTHMANN
PACIFIC BALLAST WATER GROUP
30 MARCH 2016



OVERVIEW

Mobile Testing at Golden Bear Facility

Testing and Efficacy

CSLC Results



Ongoing Testing Efforts

Great Lakes Planning

Puget Sound Voyages



Emergency Response

Deployment Readiness

Response Network

PARTICIPANTS

*California State
Lands Commission*

*Golden Bear
Facility*

*Moss Landing
Marine Laboratories*

*National Park
Service*

*Grand Portage
Tribe*


*Global Diving &
Salvage*





MOBILE TESTING AT GBF

BALLAST TANKS




METERING SKID

Portable design

Chemical prep
tank

Metering pump

Flow meter



MIXING PUMP

Submersible

300 GPM flow
rate

Chemical
sparger


3-way nozzle
outlet

Tripod mount






DYE MIXING STUDY



PROCESS



BIOLOGY RESULTS

Parameters			USCG Criteria & Standards		I48A-TD1	I48A-TD2	I24A-TD1	I24A-TD2	I24B-TD1	I24B-TD2	I8A-TD1	I8A-TD2	I18A-TD1	I18A-TD2	I18B-TD1	I18B-TD2
Full Tank Treatment Discharge (dd-mm-yy)					12-11-14	12-11-14	14-11-14	14-11-14	2-12-14	2-12-14	3-12-14	3-12-14	4-12-14	4-12-14	7-12-14	7-12-14
≥50 µm (organisms/m ³) ^b	Mean	<10	2.14 (0.38)	5.50 (0.58)	6.86 (1.1)	14.6 (1.58)	8.8 (1.2)	113.3 (4.3)	9.2 (1.3)	21.5 (1.9)	13.2 (1.5)	11.3 (1.4)	1.2 (0.5)	0.34 (0.24)		
<50 µm & ≥10 µm, Flow Cytometry (organisms/mL) ^b	Mean (S.D.)	<10	1.70 (1.2)	1.70 (1.2)	3.29 (1.7)	2.44 (1.9)	2.99 (1.7)	6.7 (2.8)	1.1 (1.4)	2.9 (1.2)	0.36 (0.85)	1.2 (1.2)	1.4 (1.2)	1.3 (1.2)		
<50 µm & ≥10 µm, ATP ^a (ng/L) ^{a,c}	Mean (S.D.)	n/r	0.56 (0.08)	0.57 (0.31)	7.26 (11.1)	14.9 (23.1)	12.8 (18.9)	7.4 (5.8)	10.4 (14.7)	2.4 (3.5)	2.7 (1.9)	23.3 (28.4)	0.61 (0.34)	7.3 (10.4)		
Indicator Microbes, <i>E. coli</i> (CFU/100 mL) ^c	Mean (S.D.)	<250	3.0 (1.0)	3.7 (3.8)	<1 (n/a)	2.26 (1.4)	1.28 (3.1)	<1 (n/a)	<1 (n/a)	2.24 (1.98)	<1 (n/a)	0.46 (0.96)	<1 (n/a)	<1 (n/a)		
Indicator Microbes, <i>Enterococci</i> (CFU/100 mL) ^c	Mean (S.D.)	<100	0.7 (0.6)	11.0 (5.0)	0.86 (1.1)	3.56 (7.4)	1.6 (1.5)	1.1 (1.95)	<1 (n/a)	0.5 (0.95)	<1 (n/a)	10.4 (21.6)	2.2 (1.3)	17.6 (19.5)		
Indicator Microbes, <i>Vibrio cholerae</i> (01/0139) (CFU/100 mL) ^c	Mean (S.D.)	<1	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)		
Indicator Microbes, Heterotrophic Plate Counts (CFU/mL) ^{a,c}	Mean (S.D.)	n/r	50.0 (66.1)	187.5 (45.1)	222.5 (442.2)	201.0 (521.1)	170.3 (441.4)	304.2 (249.6)	62.6 (149.7)	137.5 (242.9)	15.0 (27.4)	1003.1 (2074.5)	21.5 (194.9)	222.2 (645.1)		
Parameters			USCG Criteria & Standards		I48A-TD1	I48A-TD2	I24A-TD1	I24A-TD2	I24B-TD1	I24B-TD2	I8A-TD1	I8A-TD2	I18A-TD1	I18A-TD2	I18B-TD1	I18B-TD2
Partial Tank Treatment Discharge (dd-mm-yy)					12-11-14	12-11-14	14-11-14	14-11-14	2-12-14	2-12-14	3-12-14	3-12-14	4-12-14	4-12-14	7-12-14	7-12-14
≥50 µm (organisms/m ³) ^b	Mean	<10	n/a	n/a	8.2 (1.3)	6.3 (1.1)	6.8 (1.2)	95.8 (4.4)	4.7 (0.97)	5.4 (1.04)	4.1 (0.91)	6.1 (1.1)	0.18 (0.18)	0.26 (0.25)		
<50 µm & ≥10 µm, Flow Cytometry (organisms/mL) ^b	Mean (S.D.)	<10	n/a	n/a	1.9 (1.4)	0.64 (1.4)	1.9 (1.4)	1.9 (4.3)	0.64 (1.4)	0.0 (0.0)	0.0 (0.0)	0.0 (0.0)	1.4 (1.3)	1.1 (1.3)		
Indicator Microbes, <i>E. coli</i> (CFU/100 mL) ^c	Mean (S.D.)	<250	n/a	n/a	<1 (n/a)	2.3 (1.4)	1.6 (2.9)	<1 (n/a)	<1 (n/a)	1.00 (0.0)	<1 (n/a)	<1 (n/a)	<1 (n/a)	<1 (n/a)		
Indicator Microbes, <i>Enterococci</i> (CFU/100 mL) ^c	Mean (S.D.)	<100	n/a	n/a	0.5 (0.9)	0.8 (0.5)	1.0 (0.0)	<1 (n/a)	<1 (n/a)	<1 (n/a)	<1 (n/a)	<1 (n/a)	2.2 (0.86)	12.5 (10.7)		
Indicator Microbes, <i>Vibrio cholerae</i> (01/0139) (CFU/100 mL) ^c	Mean (S.D.)	<1	n/a	n/a	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)	<1/<1 (n/a)		
Indicator Microbes, Heterotrophic Plate Counts (CFU/mL) ^a	Mean (S.D.)	n/r	n/a	n/a	0.0 (0.0)	0.0 (0.0)	0.0 (0.0)	165.6 (28.4)	77.5 (140.8)	10.0 (0.0)	7.5 (4.5)	5.0 (9.1)	11.1 (8.2)	24.4 (4.1)		

TAKEAWAYS

Residence Time (RT)

- *Target dose to allow 24-hr dose & neutralize window*

Target Sustained Dose (SD)

- *Minimize bulk chemical required*
- *Prevent coating damage*

Mixing/Dosing Coordination

- *Maximize mixing, re-dose frequently*

Applied Dose Margin

- *+50% dose to offset initial demand*





ONGOING SYSTEM TESTING

OTHER SHIPS AND WATERS


GREAT LAKES




VESSEL SURVEY



FRESHWATER TREATMENT



FRESHWATER TREATMENT



Analysis		Control	Treatment	Standard
Stereo Microscopy (>50 μm)	<i>Live per cubic meter</i>	3,903 (SD 552, CV 37.8)	0 No live found	Less than 10
Flow Cytometry (10 – 50 μm)	<i>Live per milliliter</i>	112 (SD 33, CV 29.8)	0.69 (Poisson SD 0.49, CV 70.71%)	Less than 10
Epifluorescent Microscopy (10 – 50 μm)	<i>Live per milliliter</i>	73 (SD 19.61)	1.0 (SD 1.4)	Less than 10
Heterotrophic Plate Counts	<i>MPN cell per milliliter</i>	103.57 (SD 38.72)	<2 (zero) (SD <2)	Not required
E. Coli	<i>MPN cell per 100 milliliter</i>	165.7 (SD 80.52)	0 (SD 0)	Less than 250
Enterococcus	<i>MPN cell per 100 milliliter</i>	0.57 (SD 1.51)	0 (SD 0)	Less than 100





EMERGENCY RESPONSE

DEPLOYMENT READINESS & RESPONSE NETWORK

EMERGENCY RESPONSE

System ready for immediate deployment

Incorporation with standard salver services

Operator awareness: contingency solution for vessel planning



ALTERNATIVE BALLAST MANAGEMENT

STEP Application and Testing

Target Vessels





Glosten

MOBILE TREATMENT

for

Emergency Response and
Alternative Ballast Management

ALAN J. ORTHMANN

509 899 3752

AJORTHMANN@GLOSTEN.COM